

INSTALLATION INSTRUCTIONS 07401102

Model 0976 24A IP44 Kit



The 24A IP44 kit contains three parts: The rubber cover, a double-sided adhesive foam gasket, and an O-ring.



Remove the backing from one side of the foam gasket. Firmly press the adhesive side onto the motor cord strain relief.



Slide the motor cord through the rubber cover and ensure that it is in the correct orientation. Remove the backing from the foam gasket.



Firmly press the rubber cover against the adhesive foam gasket. Slide each end of the rubber cover onto the cast 'ears' of end shield.



Position the O-ring underneath one of the ears as shown. Pull the O-ring over the cord and secure underneath the opposite ear.



Ensure that O-ring is contained within the guides of the rubber cover and the installation is complete.